


# 389MHz VCO Data Sheet

## Output Frequency & Power



**Trigger**

Trigger to  
Freq & Power

Hold

Single

Continuous

Restart

Manual  
Trigger


Source  
Internal

Ext Trig Polarity  
Negative

Mode  
Analyzer

Return

## Phase Noise



**Trigger**

Trigger to  
Phase Noise

Hold

Single

Continuous

Restart

Manual  
Trigger

Source  
Internal

Ext Trig Polarity  
Negative

Return