


# 1992MHz VCO Data Sheet

## Output Frequency & Power



**Trigger**

Trigger to Freq & Power

Hold

Single

Continuous

Restart

Manual Trigger

Source Internal


Ext Trig Polarity Negative

Average Trigger OFF

Mode Analyzer

Return

## Phase Noise



**Trigger**

Trigger to Phase Noise

Hold

Single

Continuous

Restart

Manual Trigger

Source Internal

Ext Trig Polarity Negative

Average Trigger OFF

Return