


800MHz VCOData Sheet

Output Frequency & Power



Trigger

Trigger to
Freq & Power

Hold

Single

Continuous

Restart

Manual
Trigger

Source
Internal


Ext Trig Polarity
Negative

Average Trigger
OFF

Mode
Analyzer

Return

Phase Noise



Trigger

Trigger to
Phase Noise

Hold

Single

Continuous

Restart

Manual
Trigger

Source
Internal

Ext Trig Polarity
Negative

Average Trigger
OFF

Return